Coast Guard, DHS § 109.105

109.331	Firehoses and hydrants.
109.333	Fire main cutoff valves.
109.334	Working over water.
109.335	Stowage of work vests.
109.337	Fireman's outfit.
109.339	Location of fire axes.
109.347	Pilot boarding equipment.

#### Subpart D—Reports, Notifications, and **Records**

#### REPORTS AND NOTIFICATIONS

109.411	Notice and reporting of casualty.
109.415	Retention of records after casualty.
109.419	Report of unsafe machinery.
	D

109.421 Report of repairs to boilers and pressure vessels.

109.425 Repairs and alterations: Fire detecting and extinguishing equipment.

#### RECORDS

109.431 Logbook.

109.433 Logbook entries.

109.435 Record of fire fighting equipment inspection.

109.437 Crane record book.

109.439 Crane certificates.

# Subpart E—Emergency Signals

109.503 Emergency signals.

# **Subpart F—Cranes**

109.521 Cranes: General.

Cranes: Working loads. 109.525

109.527 Cranes: Operator designation.

# Subpart G—Miscellaneous

109.555 Propulsion boilers.

109.557 Flammable and combustible liquids: Carriage.

109.559 Explosives and radioactive materials.

109.563 Posting of documents.

109.564 Maneuvering characteristics.

109.565 Charts and nautical publications.

109.573 Riveting, welding, and burning operations

109.575 Accumulation of liquids on helicopter decks.

109.577 Helicopter fueling.

109.585 Use of auto pilot.

APPENDIX A TO PART 109—NAVIGATION AND Vessel Inspection Circular No. 4-78-INSPECTION AND CERTIFICATION OF EXIST-ING MOBILE OFFSHORE DRILLING UNITS

AUTHORITY: 43 U.S.C. 1333; 46 U.S.C. 3306, 6101, 10104; Department of Homeland Security Delegation No. 0170.1.

SOURCE: CGD 73-251, 43 FR 56828, Dec. 4, 1978, unless otherwise noted.

# Subpart A—General

#### § 109.101 Applicability.

No unit may be operated unless it complies with the regulations in this part.

### §109.103 Requirements of the International Convention for Safety of Life at Sea, 1974.

No self-propelled unit of more than 500 gross tons may embark on an international voyage unless it is issued the appropriate Convention certificate as described in §§ 107.401 through 107.413 of this subchapter.

# § 109.105 Incorporation by reference.

(a) Certain material is incorporated by reference into this part with the approval of the Director of the Federal Register in accordance with 5 U.S.C. 552(a). To enforce any edition other than that specified in paragraph (b) of this section, the Coast Guard must publish notice of change in the FED-ERAL REGISTER and make the material available to the public. All approved material is on file at the U.S. Coast Guard, Office of Design and Engineering Standards (CG-ENG), 2100 2nd St. SW., Stop 7126, Washington, DC 20593-7126 or at the National Archives and Records Administration (NARA). For information on the availability of this material at NARA, call 202-741-6030, or http://www.archives.gov/ to:

federal register/

code of federal regulations/ ibr  $\overline{locations.html}$ . All material is

available from the sources indicated in paragraph (b) of this section.

(b) The material for incorporation by reference in this part and the sections affected are:

American Society for Testing and Materials (ASTM)

100 Barr Harbor Drive, West Conshohocken, PA 19428-2959.

ASTM Adjunct F 1626, Symbols for Use in Accordance with Regulation II-2/20 of the 1974 SOLAS Convention as amended PCN: 12-616260-01 (1996)-109.563

International Maritime Organization (IMO)

Publications Section, 4 Albert Embankment, London, SE1 7SR United Kingdom.

### § 109.107

Resolution A.654.(16), Graphical Symbols for Fire Control Plans—109.563

[CGD 95-028, 62 FR 51208, Sept. 30, 1997, as amended by USCG 1998-4442, 63 FR 52191, Sept. 30, 1998; USCG 1999-5151, 64 FR 67182, Dec. 1, 1999; USCG-2009-0702, 74 FR 49233, Sept. 25, 2009; USCG-2012-0832, 77 FR 59781, Oct. 1, 2012]

# § 109.107 Designation of master or person in charge.

The owner of a unit or his agent shall designate an individual to be the master or person in charge of the unit.

# § 109.109 Responsibilities of master or person in charge.

- (a) The master or person in charge shall—
- (1) Ensure that the provisions of the Certificate of Inspection are adhered to: and
- (2) Be fully cognizant of the provisions in the operating manual required by §109.121.
- (b) Nothing in this subpart shall be construed as limiting the master or person in charge, at his own responsibility, from diverting from the route prescribed in the Certificate of Inspection or taking such steps as he deems necessary and prudent to assist vessels in distress or for other emergency conditions.

#### §109.121 Operating manual.

- (a) Each unit must have on board an operating manual approved by the Coast Guard as meeting the requirements of this section.
- (b) The operating manual must be available to, and written in a manner that is easily understood by, the unit's operating personnel and include the following:
- (1) A table of contents and general index.
- (2) A general description of the unit, including major dimensions, tonnages, dry bulk capacities, damage stability standard to which designed, hook load capacity, rotary table capacity, set back load capacity, drilling derrick capacity, and the identification, the maximum deadweight in pounds and kilograms, and the rotor size in feet and meters of the helicopter used for the design of the helicopter deck.
- (3) Limiting design data for each mode of operation, including draft, air

gap, wave height, wave period, wind, current, temperature, and other environmental factors.

- (4) Instructions on the use of the stability data.
- (5) Lightweight data with a comprehensive listing of the inclusions and exclusions of semi-permanent equipment, together with guidance for the routine recording of lightweight alterations
- (6) Information identifying the type, location, and quantities of permanent ballast.
- (7) Hydrostatic curves or tables.
- (8) The maximum allowable deck loadings either listed or shown on a plan.
- (9) A capacity plan showing the capacities and the vertical, longitudinal, and transverse centers of gravity of tanks and bulk material stowage spaces.
- (10) Tank sounding tables or curves showing capacities, the vertical, longitudinal, and transverse centers of gravity in graduated intervals, and the free surface data of each tank.
- (11) Stability information setting forth the maximum allowable height of the center of gravity in relation to draft data, displacement, and other applicable parameters unique to the design of the unit to determine compliance with the intact and damage stability criteria.
- (12) Examples of loading conditions for each mode of operation and instructions for developing other acceptable loading conditions.
- (13) Information concerning the use of any special crossflooding fitting for each operating condition which, if damage occurs, may require crossflooding for survival (surface units only) and the location of any valve that may require closure to prevent progressive flooding (all units).
- (14) Guidance for preparing the unit for the passage of a severe storm and the specific actions and approximate length of time to complete them or to attain a designated level of preparedness.
- (15) Guidance for operating the unit while changing its mode of operation and for preparing the unit to make a move and, for self-elevating units in